

## NMA3032 EURO SIDE MARKER INSTALLATION INSTRUCTIONS



LIFT THE END WITHOUT THE SIDEMARKER LIGHT  
AWAY FROM THE FENDER PANEL. IT IS A SIMPLE  
PRESS FIT TAB.



ONCE THE OTHER END IS FREE, SLIDE THE ENTIRE  
ASSEMBLY TOWARDS THE FRONT OF THE CAR.