

## MINI MANIA PEDAL SET FOR AUTOMATIC TRANSMISSIONS INSTALLATION INSTRUCTIONS P/N NMA2112

The aluminum pedal set for the automatic transmission consists of two pieces, the accelerator and the brake. The accelerator is attached directly over the factory pedal. The brake pedal is attached to the arm after the rubber padding is removed.

### ACCELERATOR PEDAL

Hold the aluminum accelerator over the stock pedal and carefully align. Using a marker or scribe, mark the screw hole location onto the stock pedal. Remove the aluminum pedal and drill two pilot holes for the screws using the supplied drill bit. Screw the aluminum pedal in place using the supplied screws.

### BRAKE PEDAL

Pry off the rubber cover off the brake pedal. Using a marker or scribe, mark the screw hole location onto the pedal. Remove the aluminum pedal and drill two pilot holes for the screws using the supplied drill bit. Screw the aluminum pedal in place using the supplied screws.

### MAINTENANCE

Occasionally check the screws to make sure they are tight. If they loosen over time, apply loctite to secure the screws.

Enjoy!