

NMA3032 EURO SIDE MARKER INSTALLATION INSTRUCTIONS



LIFT THE END WITHOUT THE SIDEMARKER LIGHT AWAY FROM THE FENDER PANEL. IT IS A SIMPLE PRESS FIT TAB.



ONCE THE OTHER END IS FREE, SLIDE THE ENTIRE ASSEMBLY TOWARDS THE FRONT OF THE CAR.