

INSTALLATION INSTRUCTIONS FOR CHROMED HANDBRAKE GRIP MINI MANIA PART NUMBER NMA1036

Below are instructions for the Mini Mania Chromed Brass Handbrake Grip, Part Number NMA1036. Please use caution as Handbrake boot and console can be damaged when excessive force is applied. Mini Mania is not responsible for any damages incurred during the installation of this part. Mini Mania recommends professional installation.

1. Take a firm grip on the collar of the handbrake tip just below the release button.



2. Gently wiggle and pull until it release. Remove this item and set aside.



3. Using a small screwdriver, gently lift the tab until it clears the slot. Pull on the Grip and slide towards the Release Button.



4. Insert a small screwdriver between the boot and the Handbrake Console.



5. Gently pull the screwdriver handle away from the handbrake while pushing down on the rim of the boot so the tip forces the boot rim away from the console.



6. Repeat step 5 until all tabs are released from the console. There are 3 tabs on each side of



7. Gently lift the boot assembly from the Rear and lift up and out over the handbrake handle.



8. Once the boot and grip assembly is removed, turn the boot inside out to expose the part of the grip covered by the boot. You will note the grip is secured to the boot with a plastic cable tie. Cut the cable tie and this will release the handbrake grip.



9. Insert the new grip and secure with a similar cable tie. Assemble in reverse as shown above.

ENJOY!