

NMA3032 EURO SIDE MARKER INSTALLATION INSTRUCTIONS



LIFT THE END WITHOUT THE SIDEMARKER LIGHT
AWAY FROM THE FENDER PANEL. IT IS A SIMPLE
PRESS FIT TAB.



ONCE THE OTHER END IS FREE, SLIDE THE ENTIRE
ASSEMBLY TOWARDS THE FRONT OF THE CAR.