

# INSTALLATION INSTRUCTIONS FOR LED DAYLINER

2007-2012 MINI COOPER #280603

Congratulations on your purchase of a high quality product.

Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.

Parts List		
Description		Qty
LED Dayliner		1
Brackets		2
Scotch Lock Inline Tap		2

Tools Needed for Installation
Wire Cutters
Electrical Crimping Tool
Wire Strippers

**Step 1:** Verify kit contents.

**Step 2:** Open hood and remove factory hood scoop surround.

**Step 3:** Remove black plastic factory hood scoop insert from the surround. *(Note: The four screws holding the factory insert will be reused in the DayLiner.)*

**Step 4:** Install DayLiner in Factory surround using the supplied brackets.

**Step 5:** Install hood scoop surround in hood and secure the gray power cord to the factory windshield washer lines and wires located on the underside of the hood.

**ASSEMBLY NOTE:** *The power cord will run along the hood and headlight. Ensure there are no moving parts that may cause damage to the cord.*

**Step 6:** Access the marker light located behind the front left fender liner.

**Step 7:** Run the gray LED Dayliner wire to the marker light wiring harness.

**(NOTE: You will have extra wire from the Dayliner light so remove any excess wire that is not needed.)**

**Step 8:** Tap into the factory marker light harness by stripping the black protective cover back exposing the brown and blue wires using wire strippers.

**(CAUTION: DO NOT CUT THE WIRES IN HALF!!!)**

**Step 9:** Attach the Red (+) wire to the Factory Blue (+) wire and the Black (-) wire to the Factory Brown (-) wire using the supplied scotch locks and your electrical crimping tool.

**Step 10:** Verify everything is connected securely and turn the vehicle on to test the LED Dayliner Light.

**(NOTE: Your LED Dayliner Lights will only operate when the vehicle is on and the daytime running lights are on or when the low beams are in use. They will not operate with high beams.)**

**Note: If your lights do not turn on verify the connection between the Factory and Putco wiring is secured properly.**

INSTRUCTION # IN280603-MAR 2012

## LIMITED WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.